



Acer Aspire One D250-1151 3G Card Replacement

This guide will show you how to remove the 3G Card

Written By: Donny McKay





TOOLS:

- [Phillips #1 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — 3G Card



- Place the computer face down on a flat surface.

Step 2



- Unscrew the smallest panel using a Philips PH1 screwdriver in a counterclockwise motion.

Step 3



- Open the panel by lifting up in the small groove using a finger, Plastic Opening Tool or similar device.

Step 4



- Slide the 3G card forward until it is not connected.

Step 5



- Remove the 3G Card from the compartment.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 07:33:13 AM.